

WIRING INFORMATION 1999 Ford Taurus

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT	LT.GREEN/PURPLE or YELLOW	Ignition Harness
STARTER	RED/LT. BLUE	Ignition Harness
IGNITION	RED/LT. GREEN	Ignition Harness
ACCESSORY	GRY/YEL & RED/BLK	Ignition Harness
SECOND ACCESSORY	BLACK/LT GREEN	Ignition Harness
POWER DOOR LOCK (-)	PINK/YELLOW	Left Connector Below Fuse Box Under Dash
POWER DOOR UNLOCK (-)	PINK/GREEN	Left Connector Below Fuse Box Under Dash
PARKING LIGHTS (+)	BROWN	Headlight Switch
DOOR TRIGGER (-)	GREEN/ORANGE	Headlight Switch
TRUNK TRIGGER (-)	BLACK/PINK	Light In Trunk
TRNK/HTCH RELEASE	PINK/YELLOW (-) or GRAY/RED (+)	At Trunk Release Switch
FACTORY ALARM ARM	Arms with Lock	
FACTORY ALARM DISARM (-)	PINK/WHITE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	YELLOW/WHITE	Ignition Coil Behind Air Intake Manifold
BRAKE WIRE (+)	RED/LT. GREEN	Brake Switch
HORN TRIGGER (-)	PURPLE/ORANGE DOTS	Gray Connector Right Of Column
LEFT FRONT WINDOW UP	BLACK/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	TAN/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

This vehicle may be equipped with PATS. This must be bypassed when installing a remote start system.

